




Dual 8K
SPEEDLINK 2

SG5 Pro



QUICK START GUIDE

WHAT'S IN THE BOX



Wireless
Mouse



Charging
Dock



USB Type-C
Adaptor



Nano USB
Receiver



USB Type-C
Cable



Mouse
Feet



User
Manual




Grip Tape

KNOW YOUR PRODUCT



1



2




3



4



5



6




7

- ① Nano Receiver Port
- ② Snap-On Magnetic Charging
- ③ Function Indicator
- ④ Report Rate Button
- ⑤ CPI Button
- ⑥ Power Switch
- ⑦ Nano Receiver Storage

DUAL 8K REPORT RATE



8000 Hz supported for both wired and wireless connections.
Press the report rate button to switch between different report rates.
Adjustable via Desktop & Web-Based Software: 125 ~ 8000 Hz.



Report Rate Button / Indicator

Indicator	Report Rate
	125 Hz = 8 ms
	500 Hz = 2 ms
	1,000 Hz = 1 ms
	2,000 Hz = 0.5 ms
	4,000 Hz = 0.25 ms
	8,000 Hz = 0.125 ms

*The report rate indicator will turn off if not used for 10s.


CPI ADJUSTABLE



Press the CPI button to switch between the default resolutions:
400, 800, 1000, 1200, 1600, 2000 CPI.
Adjustable via Desktop & Web-Based Software: 50 ~ 30,000 CPI.



CPI Indicator 1



CPI Button / Indicator 2

Indicator	Default Resolution
	400 CPI
	800 CPI
	1,000 CPI
	1,200 CPI
	1,600 CPI
	2,000 CPI


CONNECT 2.4G NANO RECEIVER




① Turn the mouse power switch on.



② Take out the Nano receiver.



③ **Laptop Use:** Plug the receiver into the laptop's USB port or use the Type-C adaptor to connect the receiver to the laptop's Type-C port.




④ **Desktop Use:** Plug the receiver into the charging dock, then connect with PC's USB port for wireless signal anti-interference.


CONNECTING USB WIRED



The mouse will switch from wireless to wired mode when the USB Type-C cable is connected.
Note: While in wired mode, the mouse charges simultaneously.



Connect to the Desktop Computer




Connect to the Laptop Computer

CHARGING & INDICATOR



① Wireless Charging Mode



Snap-On

② Wired Charging Mode



Type-C

Mouse Indicator

- No Light -- Working
- Flashes Red -- Below 15% Battery
- Solid Red -- Charging
- Solid Green -- Fully Charged


DIY DISPLAY EFFECT



Tailor Made Pre-Cut



Easy to Apply



Pattern images of the grip tape are for reference only,
shall be subjected to the actual product.


WIRELESS 8KM-ESPORT EDITOR

Master Your Gaming Configuration

Optimize your mouse settings with simple combinations and programming functions. Customize buttons, sensitivity, and macros, then save them to the mouse's on-board memory.

① Download Version: bloody.com/en/download/

Supports Windows 10 and later versions.



② Web-Based Version: hub.bloody.com

Compatible with all Chromium-based browsers on Windows, Mac and Linux. Examples: Chrome, Edge.



You can also access the web-based version directly via lifting the mouse and holding the middle + right mouse buttons for 3 seconds.

Q & A



Question

When connected in 2.4G wireless mode, the mouse sometimes lags.

How can I fix this?

Answer

Check the following:

1. Ensure the USB Nano receiver is connected to the adaptor and the USB Type-C cable is properly plugged in.
2. Make sure the wireless environment is within 30-100 cm, without obstacles or metal objects.
3. Ensure there are no strong wireless routers or other interference sources within 100 cm.

Question

What should I do when the software prompts for firmware update?

Answer

Please follow the steps below to complete the update:

1. Connect the mouse via wired mode and plug the receiver into your computer's USB port.
2. Confirm that the software recognizes both the mouse and receiver.
3. When the software prompts for firmware upgrade, click the upgrade button to finish the process.

Question

How do I pair a newly-purchased receiver?

Answer

Please follow the steps below:

1. Plug in both the mouse and receiver, then click the pairing button to re-pair.
2. Go to the device settings page, click the pairing button. Once the software shows pairing successful, the wireless mouse is ready for use.

TECH SPEC



Wireless Technology:	SPEEDLINK 2 Wireless 8K Technology
Sensor:	S-Tier 30K (PAW3950) Sensor
Operation Range:	>10m
Resolution:	50-30,000 CPI (by Software)
Default Resolution:	400-800-1,000-1,200-1,600-2,000 CPI
Tracking Speed:	750 IPS
Acceleration:	50G
LOD Setting:	0.7 mm / 1 mm / 2mm (by Software)
Wired Report Rate:	125-500-1000-2000-4000-8000 Hz
Wireless Report Rate:	125-500-1000-2000-4000-8000 Hz
Wireless Transmission Latency:	0.125 ~ 8 ms
Key Response:	0.5 ms
Li-Po Battery:	300 mAh
Charging Type:	USB Type-C / Charging Dock
Optical Micro Switch:	Over 100-Million Clicks (Left / Right Button)
Wheel:	Over 800,000 Scrolls
Size:	125 x 64 x 40 mm

WARNING STATEMENT

The following actions may cause damage to the product:

1. Disassembling, bumping, crushing, or throwing into the fire can cause irreparable damage due to lithium battery leakage.

2. Avoid exposing to strong sunlight.


3. Follow local laws for battery disposal; recycle if possible.
Improper disposal may cause fire or explosion.

4. Avoid charging in environments below 0°C.

5. Do not remove or replace the battery.

6. Do not use chargers with outputs from 6V to 24V.

Use a 5V charger to avoid damage.



www.Bloody.com



Scan for E-Manual